

Sharklet



LED Linear Strip Light

Tel: +86(0)755 29985870

Web: www.gielight.com

Email: gielight@gielight.com

Address: Building B, Jinfeng Industrial Zone, Yonghe Road, Heping community, Fuhai Street, Bao'an District, Shenzhen, China.


Product Appearance



Product Features

- 1. ETL,CETL, DLC listed.
- 2. Power optional: 4FT 30W-35W-40W,8FT 60W-70W-80W.
- 3. Lumen efficiency: 140lm/w. ,
- 4. 0-10V dimmable driver.
- 5. Input voltage: 100-277VAC .
- 6. Installation: Surface mounted // Suspension .
- 7. Five years' warranty.
- 8. Customers can install microwave sensor and bluetooth by themselves.


Product Dimension




| Model | size | A (inch)(mm) | B (inch)(mm) | C (inch)(mm) |
|----------------|------|------------------|-----------------|-----------------|
| ST-4FT-40W-L-H | 4FT | 48.03" 1220mm | 2.95" 75mm | 2.99" 76mm |
| ST-8FT-80W-L-H | 8FT | 95.98" 2438mm | 2.95" 75mm | 2.99" 76mm |

Specification


| Model | size | Power | Input Voltage | Dimmable | PF | Light Efficacy | Ra | CCT |
|----------------|------|-----------|---------------|----------|------|----------------|----|-----------------------|
| ST-4FT-40W-L-H | 4FT | 30/35/40W | AC100-277V | 0-10V | >0.9 | 140/lm | 80 | 3500/4000/5000K/6500K |
| ST-8FT-80W-L-H | 8FT | 60/70/80W | AC100-277V | 0-10V | >0.9 | 140/lm | 80 | 3500/4000/5000K/6500K |



Features & Benefits



Wirng Diagam



Parameters



| Model NO. | | HD08VR |
|-------------------------|-----------------------------|--|
| MICROWAVE INFORMATION | Frequency | 5.8GHz±75Hz |
| | Microwave Power | <0.3mW |
| | Installation Height | 5m/16.4Max. |
| | Detection Distance | ≥3m/9ft |
| | Detection Angle | 30-150° (Without Glass Cover) |
| SENSOR PARAMETER | Detection Area | 25%/50%/75%/100% |
| | Holdtime | 5s/ 30s/ 1min] 2min/ 3min/ 15min/ 20min/ 25min/ 30min/ 45min/ 60min/ 90min/ 120min |
| | Daylight Threshold | Disable/400Lux/350Lux/300Lux/250Lux/200Lux/120Lux/ 80Lux/50Lux/30Lux/10Lux/2Lux |
| | Standby Dimming Level | 10%/20%/30%/50% |
| | Standby Period | 0s/5s/30s/1min/2min/3min/5min/10min/15min/20min/ 25min/30min/45min/60min/+∞ |
| | Dusk/Dawn Sensing/Photocell | Daylight threshold as 30lux/ 50lux/ 80lux/ 120lux/ 200Lux/ 250Lux/300Lux/ 350Lux/ 400Lux Standby period as +∞ Standby dimming level as 10%/20%/30% |
| | Daylight Harvesting | 1. Adjust "daylight" value higher than 50lux 2. Preset "standby period" 0S 3. press MW/PIR button 3 times till MW/PIR icons both blinking on LCD screen, daylight harvesting function enabled. (With BLE version, press DH button, daylight harvesting function enabled.) |
| BLUETOOTH INFORMATION | Wireless Control Range | ≥20m/65ft |
| | APP Download | Supported in both APP Store and Google Play Market |
| INPUT | Input range | 12VDC |
| | Voltage Range | 10-15VDC |
| | Current | ≥40mA |
| OUTPUT | Signal | DIM 0-10V |
| | Connection | TipDIM+、RingVCC、SleeveGND |
| | Stang-by Power | <0.5W |
| ENVIRONMENT | Working Temp | -25°C~+60°C |
| | Storage Temp | -40°C~+80°C Humdity:85% (non-xondensation) |
| CERTIFICATE & STANDARDS | Environmental Requirements | In accordance with CE ROHS |
| | IP Rating | IP20 |

Parameters

| Model | Sensor Type | Connector | Controller |
|---|-------------|------------|----------------------|
| HD08VR-M-1 | Microwave | Audio Jack | Remote Control HD05R |
| HD08VR-MB-1  | | | HALSEN BLUE APP |

Networked Lighting Controls: HAISEN BLUE

Detection Coverage



HD08VR-MA-1

Highest mounting height is 6m




This figure indicates the maximum distance at the highest mounting height with 100% sensitivity.

Well Detected Area Possibly Detected Area

Performance

1. Daylight Harvesting

1. Adjust "daylight" value higher than 50lux
 2. Preset "standby period" 0S
 3. Press MW/PIR button 3 times till MW/PIR icons both blinking on LCD screen, daylight harvesting function enabled.
- blinking on LCD screen, daylight harvesting function enabled.



When ambient brightness is lower than preset lux level, sensor will turn on light automatically and keep dimming according to the change of the ambient brightness; when outside is getting darker, the inside will be brighter, and brighter darker.


Light OFF when ambient brightness becomes higher than the preset lux level.

2. Dusk/Dawn function

HD08VR is able to differentiate artificial light brightness from natural light after installed inside the fixture, and automatically turn off light when ambient brightness exceeds preset lux level.

Precondition of Dusk/Dawn function:

1. Standby period is +∞ ;
2. Standby dimming level is on 10%, 20% or 30%;
3. Daylight threshold is on 30lux/ 50lux/ 80lux/ 120lux/ 200Lux/ 250Lux/300Lux/ 350Lux/ 400Lux



3. With Dusk/Dawn function




With insufficient ambient brightness, sensor turns on light and keeps it at standby dimming level even if there is no motion or presence.




When sensor detects motion or presence it will bring the light level up to 100%.



After motion is no longer detected, fixture remains at 100% for hold time.



After pre-set hold time period it will dim light to standby dimming level again and always keep it.



With sufficient ambient brightness, sensor will turn OFF light automatically.


4. Without daylight disabled




Sensor turns ON light when motion is detected.



Sensor keeps for a hold time period after motion leaves




Sensor dims light to standby dimming level after hold time if there is still no motion



Sensor turns OFF light after standby period

5. With Daylight Threshold




With sufficient daylight, the sensor keeps light OFF even motion gets detected




With insufficient daylight, the sensor turns light ON when motion gets detected



After there's no motion detected, the sensor keeps light ON 100% for holdtime.




After holdtime, sensor dims light to standby dimming level for standby period. if the standby period has been set as 0s, sensor turns light OFF automatically after holdtime.



The sensor turns OFF light automatically after the standby period when there's no motion detected.

APP DOWNLOAD

Our app HAISEN BLUE has been uploaded onto APP Store & Google Market





SIGN UP/LOG IN

Please select the region as US (because the server is located in the US.) if you signing up with phone number; or with mail address without region restriction.

Log in if you already have account.

PROJECT MANAGEMENT




CREATE PROJECT


The app is specially designed for industrial project application, not only to control the SMART SENSORS but also HAISEN's Emergency Driver. It requires you to start a new project first before going on add or control devices.

CONTROL

Select the sensor or group to control it.




CONTROL PAGE -1



CONTROL PAGE -2

HIGH-END TRIM

High-end Trimming is a very practical function for customers who prefer to have less than 100% brightness everytime the sensor detects motion, and our steps to approach it is very easy.



STEPS

- Dim the light to a level, for example 76%, simply by moving the block.
- Press "sensor" at the bottom center and start making a program
- Then press "A" means running automation.
- After setting, the sensor works as dimming to only 76% everytime it detects motion.

DAYLIGHT HARVESTING

Daylight Harvesting function offers the possibility to dim the light brightness along with the change of natural brightness; when outside gets darker, indoor environment should become brighter.




STEPS


- Press "sensor" at the bottom center and start making a program, daylight must be chosen higher than 50lux, meanwhile the standby period should be 0S.
- Back to the mainpage and press "DH" button

Emergency LED Driver

Wiring Diagram



Dimensions




Operation

AC Operation:

AC power is present, The LED load from the LED driver is normal power supply, AC LED driver output current can not exceed 150W or 4A, the emergency driver is charging in a standby mode. The green LED light flashes indicates that it is charging. The green LED light on indicates that it is full charged. After the AC power supply working 48h, The emergency LED drive will automatically from AC power working switch into emergency working mode for 30S every month and then automatically backs to the working mode of the AC power supply, the AC power supply works per year for automatically from the AC power mode backs to the working emergency mode until the emergency discharge is completed.


Emergency operation:

When the AC power goes out, The emergency driver detects the AC power outage and automatically switch to the emergency mode.



Indicator light introduction

- ① Green/flashing: Charging
- ② Green/on: Full-charged
- ③ Red/on: Discharging(emergency mode)
- ④ Red/flashing: Discharging(emergency mode) finished soon
- ⑤ Yellow/on: Error



Test switch introduction

Press the test switch to confirm whether the emergency function is normal



IMPORTANT SAFEGUARDS

When using electrical equipment, basic safety precautions should always be followed including the following





READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- Risk of fire or electric shock. Luminaire wiring and electrical parts may be damaged when drilling for installation of LED Emergency Backup. Check for enclosed wiring and components.
- Risk of fire or electric shock. This LED Emergency Backup installation requires knowledge of luminaire, electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician.
- Before installing, make certain the AC power to the fixture is off.
- The electrical rating of this product is 100-347Vac. Installer must confirm that there is 100-347Vac to the fixture before installation.
- To prevent electrical shock only mate unit connector after installation is complete and before the AC power to the fixture is back on.
- This LED Emergency Backup unit requires an un-switched AC power source of 100-347Vac, 50/60Hz. The AC driver must be on the same branch circuit as the LED Emergency Backup unit.
- Do not let power supply cords touch hot surfaces.
- Do not mount near gas or electric heaters.
- Do not use outdoors.
- Do not connect battery pack connector until all other wiring is complete and AC power is on.
- The emergency LED driver is for use with grounded, UL listed LED luminaires, shall be enclosed by the LED luminaire and bonded to the grounding of LED luminaire.
- Verify that all replacement lamp types marked on the installed luminaire are also identified as suitable for use with this emergency battery pack.
- The battery pack is fixed by the screw and the indicator lamp is attached to the shell of the luminaire by 3M tape.
- Equipment should be mounted in locations and at heights where it is not be subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer and may cause an unsafe condition.
- Do not use this equipment for other than its intended use.
- Use with grounded, UL Listed, dry or damp location rated fixtures.



Installation


Surface Mounted Installation




Installation

Suspension installation


1. Drill two holes in the ceiling with electrodrill, put the hook into the hole.




2. Put the hook into the holes as picture.




3. One side of safety rope to connect the hook, the other connect the lifting hook.




4. Turn off power, and make wiring connections with terminalcap.(see wiring instrucion below).



5. Insert the terminal block and wires into the strip.



6. Insert the wire terminal joint to the wire entry.




Watt Tunbale: Switch 1 CTT Tunbale Switch 2=
 4ft 40w 35w 30w 6500K 5000K 4000K 3500K
 8ft 80w 70w 60w


Installation

Connection for option


1. Fix the connection bracket on the wall.




2. Insert the strip light into the connection bracket, then drill holes at a suitable position in the wall for installing the next strip light.



3. Fix the lamp body on the wall by screws, complete the installation; repeat the previous procedure to install the 3rd strip light, 4th strip light etc.




4. Wiring schematic as shown.




Installation

Connection for option


5. Pass wires through the knockout hole, fix the wires with 3M glue.




6. The same type of electronic wires are inserted into the same quick connector and combined into a parallel circuit.




7. Tighten the wires in the quick connector, as the photo shows below.



8. As shown in the figure, it is the diagram of wiring completion.



9. After finished wire connecting and install back the housing, Light up.




The Installation must be carried out by a qualified electrician.

Packing/weight

| Part NO. | Outer Carton Size (LxWxH) | Qty/Carton (pcs) | Net weight (kg)(lbs) | Gross weight (kg)(lbs) | 20GP (QTY) | 40HQ (QTY) |
|----------------|--|------------------|----------------------|------------------------|------------|------------|
| ST-4FT-40W-L-H | (1230x234x242mm) (48.42"x9.21"x9.53") | 9PCS | 1.5kg 3.31lbs | 15.3kg 33.73lbs | 3600 | 8496 |
| ST-8FT-80W-L-H | (2455x160x165mm) (96.65"x6.30"x6.5") | 4PCS | 2.8kg 6.17lbs | 13.2kg 29.1lbs | 1664 | 3928 |

Packing





- 1.The installation and maintenance must be completed by electricians or professionals.
- 2.Please cut off the power before installation and maintenance.
- 3.The fixture is not allowed to be covered by thermally insulating material.
- 4.Please keep away from the corrosive substance,and keep the fixture dry and clean.
- 5.Working tempe:-4°F~104°F,storage temperature:-22°F~140°F.